



- Take three Height Measurements
- Take three Width Measurements
- **It is recommended and common practice to deduct a ¼" of the smallest width and ¼" of the smallest height measurement. Thus it can be assured that the shutter fits into the opening.**
- Note on order form that shutter is recess mount!

General Measurement considerations for recess**mount:**

- Make sure that there are no obstructions in the path of the shutter that might have to be removed (i.e. door handles)
- Verify that the surface is suitable to install the shutter and is able to support the weight of the shutters
- Verify that the rails (especially end retention rails) can be installed inside the window frame
- Verify that the shutter can be installed plumb, level, and square.
- Make sure that the desired operator can be installed
- Determine how the shutter can be brought to site (i.e. needs to fit into a lift like in apartment buildings)
- Check if any other equipment such as scaffolding or boom lift is needed.
- For more information – check Rollac' Installation Instructions